


FIG. 1



FIG, 2

F16,3

Element #1	Location 0
Element #2	Location 1
Element #1	Location 2
Element #3	Location 3
Element #1	Location 4
0	Location 5
•	
•	
0	LOCATION I

F16. 4

Pointer	Description
СР	Current Pointer – points to the next element in the table to be transmitted
AP FP	Actual Pointer – points to the time slot that corresponds to actual time
FP	Free Pointer – points to the next entry that corresponds to an empty slot (no element)

FIG. 5

